



Defining a Short Key for the Layer Manager

If you frequently name layers, you might find it convenient to associate a keystroke (short command) to post the Layer Manager dialog as opposed to choosing Layer Mgr from the SETUP pop-up menu.

Both ExpertCAD and ExpertCAD3D use the same function to manage layer names. In your custom customization configuration file:

```
ExpertCAD: (UNIX .cimcad) (Windows expcad.cfg)
ExpertCAD3D (UNIX .cimcad3d) (Windows expcad3d.cfg)
```

Append the following 2 lines:

```
-- This short key will post the Layer Manager dialog  
short a postLayerManagerPanel
```

This will make cause the key 'a' to post the layer manager dialog. If you wish to use a different key, change 'a' to whatever key you want to associate it to (e.g. F2).