

How to Get Your Default Values or Rules Back in Insight

The information in this tip applies to:

- Prospector (all versions)

SUMMARY

It is possible to get back the default value or rule after you have made a change in the User database in PowerSource Insight. To get the default back, simply backspace out the changed value or rule to clear it, then hit the Enter key.

MORE INFORMATION

Let's say you changed the **Step Over** value in Insight to **.2** and you would like to get back whatever its default was:

Property	Value
Maintain Cutting Convention	"No"
Step Over	.2
Cut Angle	45

The **Step Over** value was changed but now you want the default back.

Click in the **Step Over** value field, and backspace it out:

Property	Value
Maintain Cutting Convention	"No"
Step Over	

Click in the value field and backspace it out, then hit the Enter key.

When you hit enter, PowerSource automatically gets the default value for **Step Over**:

Property	Value
Maintain Cutting Convention	"No"
Step Over	"Lace, Tool, Maximum Step Over"

PowerSource will automatically get and fill in the default value for **Step Over**.

Remember to save your changes.